



**NOTES:**

1. PVC LATERAL SHALL BE ABANDONED BY CUTTING THE PIPE NEAR THE WYE AND INSTALLING A WATERPROOF PVC CAP ON THE PIPE ENDS. ABANDON ALL OTHER PIPES BY CUTTING THE PIPE NEAR THE WYE, SEALING THE PIPE ENDS WITH A FERNCO FLEXIBLE COUPLING AND PVC PLUG OR WING-NUT STYLE RUBBER EXPANSION PLUG AND POURING A CONCRETE COLLAR AROUND THE WYE AND PLUG AS DIRECTED BY THE VILLAGE.
2. ABANDON THE REMAINDER OF THE EXISTING PIPE WITHIN 5' OF THE BACK OF CURB OR EDGE OF SHOULDER BY FILLING WITH A FLOWABLE FILL. FLOWABLE FILL SHALL BE CONCRETE, SLURRY OR APPROVED EQUAL.

SCALE: NTS

**SANITARY LATERAL ABANDONMENT AT  
EXISTING MAIN**

DETAIL: SAN - 6

DATE: 10-20-22

APPROVED BY: MATT FINEOUR

**VILLAGE OF PLEASANT PRAIRIE**  
KENOSHA COUNTY, WISCONSIN